- 3. All works shall be measured subject to the following tolerances.
- I. linear measurement shall be measured to the nearest 0.01m.
- II. Areas shall be measured to the nearest 0.01 sq.m
- III. Cubic contents shall be worked-out to the nearest 0.01 cum
 - 4. Same type of work under different conditions and nature shall be measured separatelyunder separate items.
 - 5. The bill of quantities shall fully describe the materials, proportions, workmanships and accurately represent the work to be executed.
 - 6. In case of masonry (stone or brick) or structural concrete, the categories shall be measured separately and the heights shall be described:
 - a) From foundation to plinth level
 - b) From plinth level to first floor level
 - c) From Fist floor to second floor level and so on.

1.3 REQUIREMENTS OF ESTIMATION AND COSTING

- 1. Estimate gives an idea of the cost of the work and hence its feasibility can be determined i.e. whether the project could be taken up with in the funds available or not.
- 2. Estimate gives an idea of time required for the completion of the work.
- 3. Estimate is required to invite the tenders and Quotations and to arrange contract.
- 4. Estimate is also required to control the expenditure during the execution of work.
- 5. Estimate decides whether the proposed plan matches the funds available or not.

1.3.1 PROCEDURE OF ESTIMATING OR METHOD OF ESTIMATING.

Estimating involves the following operations

- 1. Preparing detailed Estimate.
- 2. Calculating the rate of each unit of work
- 3. Preparing abstract of estimate

1.3.2 DATA REQUIRED TO PREPARE AN ESTIMATE

1. Drawings i.e. plans, elevations, sections etc.

- 2. Specifications.
- 3. Rates.

1.3.3 DRAWINGS

If the drawings are not clear and without complete dimensions the preparation of estimation become very difficult. So, it is very essential before preparing an estimate.

1.3.4 SPECIFICATIONS

General Specifications: This gives the nature, quality, class and work and materials in general terms to be used in various parts of wok. It helps no form a general idea of building.

Detailed Specifications: These gives the detailed description of the various items of work laying down the Quantities and qualities of materials, their proportions, the method of preparation workmanship and execution of work.

1.3.5 RATES

For preparing the estimate the unit rates of each item of work are required.

- 1. for arriving at the unit rates of each item.
- 2. The rates of various materials to be used in the construction.
- 3. The cost of transport materials.
- 4. The wages of labor, skilled or unskilled of masons, carpenters, Amador, etc.,

1.3.6COMPLETE ESTIMATE

Most of people think that the estimate of a structure includes cost of land, cost of materials and labor, but many other direct and indirect costs included and are shown below.

L.S.Items.

The following are some of L.S. Items in the estimate.

- 1. Water supply and sanitary arrangements.
- 2. Electrical installations like meter, motor, etc.,
- 3. Architectural features.
- 4. Contingencies and unforeseen items.

In general, certain percentage on the cost of estimation is allotted for the above L.S.Items Even if sub estimates prepared or at the end of execution of work, the actual cost should not exceed the L.S.amounts provided in the main estimate.

1.3.8 WORK CHARGED ESTABLISHMENT:

During the construction of a project considerable number of skilled supervisors, work assistance, watch men etc., are employed on temporary basis. The salaries of these persons are drawn from the L.S. amount allotted towards the work charged establishment. That is, establishment which is charged directly to work. AnL.S.amount of $1\frac{1}{2}$ to 2% of the estimated cost is provided towards the work charged establishment.

1.4 METHODS OF TAKING OUT QUANTITIES

The quantities like earth work, foundation concrete, brickwork in plinthand super structure etc., can be workout by any of following two methods:

- a) Long wall short wall method
- b) Centre line method.
- c) Partly centre line and short wall method.

1.4.1 LONG WALL-SHORT WALL METHOD

In this method, the wall along the length of room is considered to be longwall while the wall perpendicular to long wall is said to be short wall. To get thelength of long wall or short wall, calculate first the centre line lengths of individual walls. Then the length of long wall, (out to out) may be calculated after adding half breadth at each end to its centre line length. Thus the length of short wall

Measured into in and may be found by deducting half breadth from its centre linelength at each end. The length of long wall usually decreases from earth work tobrick work in super structure while the short wall increases. These lengths are multiplied by breadth and depth to getquantities.

1.4.2 CENTRE LINE METHOD

This method is suitable for walls of similar cross sections. Here the totalcentre line length is multiplied by breadth and depth of respective item to get the total quantity at a time.

When cross walls or partitions or verandah walls joinwith main all, the centre line length gets reduced by half of breadth for each junction. Such junction or joints are studied carefully while calculating total centreline length. The estimates prepared by this method are most accurate and quick.

1.4.3 PARTLY CENTRE LINE AND PARTLY CROSS WALL METHOD

This method is adopted when external (i.e., around the building) wall isof one thickness and the internal walls having different thicknesses. In such cases, centre line method is applied to external walls and long wall-short wall method is used to internal walls. This method suits for different thicknesses walls and differentlevel of foundations. Because of this reason, all Engineering departments are practicing this method.

1.4.4 DETAILED ESTIMATE

The preparation of detailed estimate consists of working out quantities of various items of work and then determines the cost of each item. This is prepared in two stages.

I) DETAILS OF MEASUREMENTS AND CALCULATION OF QUANTITIES

The complete work is divided into various items of work such as earth work concreting, brick work, R.C.C. Plastering etc., The details of measurements are taken from drawings and entered in respective columns of prescribed preformed. The quantities are calculated by multiplying the values that are in numbers column to Depth column as shown below:

Details of measurements form

S.No	Description of Item	No	Length (L) m	Breadth (B) m	Depth/ Height (D/H)m	Quantity	Explanatory Notes
7				(1			
					0		3

ii)

Abstract of Estimated Cost:

The cost of each item of work is worked out from the quantities that already computed in the details measurement form at workable rate. But the total cost is worked out in the prescribed form is known as

abstract of estimated form. 4% of estimated Cost is allowed for Petty Supervision, contingencies and Unforeseen items.

Types of Estimates

ABSTRACT OF ESTIMATE FORM

Item No.	Description/ Particulars	Quantity	Unit	Rate	Per (Unit)	Amesant

The detailed estimate should accompanied with

- I) Report
- ii) Specification
- iii) Drawings (plans, elevation, sections) iv)

Design charts and calculations

v)Standard schedule of rates.

1.4.5 FACTORS TO BE CONSISDERED WHILE PREPARING DETAILED

ESTIMATE

i) Quantity and transportation of materials:

For bigger project, the requirement of materials is more. such bulk volume of materials will be purchased and transported definitely at cheaper rate.

ii) Location of site:

The site of work is selected, such that it should reduce damage or in transit during loading, unloading, stocking of materials.

iii) Local labor charges:

The skill, suitability and wages of local labors are considered while preparing the detailed estimate.

1.4.6 DATA

The process of working out the cost or rate per unit of each item is called as Data. In preparation of Data, the rates of materials and labor are obtained from current standard scheduled of rates and while the quantities of materials and labor required for one unit of item are taken from Standard Data Book.

1.4.7 FIXING OF RATE PER UNIT OF AN ITEM

The rate per unit of an item includes the following:

1) Quantity of materials & cost:

The requirement of materials is taken strictly in accordance with standard data book(S.D.B). The cost of these includes first cost, freight, insurance and transportation charges.

2) Cost of labour:

The exact number of labourers required for unit of work and the multiplied by the wages/ day to get of labour for unit item work.

3) Cost of equipment (T&P):

Some works need special type of equipment, tools and plant. In such case, an amount of 1 to 2% of estimated cost is provided.

4) Overhead charges:

To meet expenses of office rent, depreciation of equipment salaries of staff postage, lighting an amount of 4% of estimate cost is allocated.

1.4.8 METHODS OF PREPARATION OF APPROXIMATE ESTIMATE

Preliminary or approximate estimate is required for studies of various aspects of work of project and for its administrative approval. It can decide, in case of commercial projects, whether the net income earned justifies the amount invested or not. The approximate estimate is prepared from the practical knowledge and cost of similar works. The estimate is accompanied by a report duely explaining necessity and utility of the project and with a site or layout plan. A percentage 5 to 10% is allowed for contingencies. The following are the methods used for preparation of approximate estimates.

- a) Plinth area method
- b) Cubical contents methods